

# **AVENTHO 100**WIRELESS ON-EAR HEADPHONES

DISASSEMBLY INSTRUCTIONS TO REMOVE THE BATTERY

- PROFESSIONAL STAFF ONLY -

AVENTHO 100 2

1.	Introduction	. 3
2.	Information for Germany on disposal in accordance with the Electrical and Electronic Equipment Act (ElektroG) and the WEEE Directive 2012/19/EU	. 3
3.	Disposal of batteries	. 3
/1	Removing the hattery	7

AVENTHO 100

#### 1. Introduction

In accordance with the Electrical and Electronic Equipment Act (ElektroG) and the European WEEE Directive 2012/19/EU, electrical and electronic equipment must be disposed of separately from household waste at the end of their life.

If the device is operated with batteries, these must be removed before disposal. If batteries are permanently installed in the device, they must be removed by professional staff for safety reasons.

These disassembly instructions show how to proceed.

# 2. Information for Germany on disposal in accordance with the Electrical and Electronic Equipment Act (ElektroG) and the WEEE Directive 2012/19/EU



- The symbol of the crossed-out dustbin on the product, in the operating instructions or on the packaging means that electrical and electronic devices must be disposed of separately from household waste at the end of their life cycle.
- Always dispose of used equipment in accordance with applicable regulations.
- For the return of old equipment, batteries and rechargeable batteries, there are free collection points or a free return to beyerdynamic, as well as other acceptance points for reuse. The addresses are available at the local city or municipal administration.
- Dealers for electronic equipment are generally obliged to take back waste electrical/electronic equipment free of charge. This obligation also applies to sales via remote communication.
- For further information, please contact the local authorities or the dealer from whom the product was purchased.
- The consumer/end-user is responsible for the deletion of personal data on the waste electrical/electronic equipment.

### 4. Removing the battery



Caution:

Before removal discharge the battery. For this product a non-destructive removal of the battery by the end user is not possible.

Due to the safety risk, this activity may only be carried out by professional staff. Please contact beyerdynamic or consult independent professional staff.


- Discharge the battery before disposing of it.
- Remove the ear pad from the right (R) ear cup by turning the ear pad counter-clockwise.



Loosen the three screws of the acoustic baffle of the right ear cup with a cross-head screwdriver (PH0X40) and remove the acoustic baffle.



Loosen the six screws inside the ear cup with a cross-head screwdriver (PH0X40).



### 3. Disposal of batteries

Dispose of batteries separately after use from the product in accordance with applicable regulations. They must not be disposed of in household waste. The return is free



 of charge for consumers/end users.
 Before disposal, discharge and remove the batteries. AVENTHO 100 4

- Remove the inside of the ear cup and turn it over. The battery is located on the back of the inside of the ear cup.
- Remove the adhesive tape.



- Disconnect the conductor tracks on the battery by hand via the plug connection.
- Disconnect the plug of the red/white/black cables by hand.




Loosen the adhesive connection under the battery with a suitable flat tool and pull the battery out under the conductor tracks.

#### Caution:

The battery is attached to the housing with a double-sided adhesive tape to prevent vibrations. Some effort is therefore required to remove the battery.

If necessary, you can use a soft, blunt tool, e.g. a plastic spatula or the cover of the battery housing.

Make sure that the battery is not damaged when you remove it.



## beyerdynamic GmbH & Co. KG Theresienstraße 8 · 74072 Heilbronn / Germany Phone +49 7131 617-300 · E-Mail info@beyerdynamic.com www.beyerdynamic.com

For further distributors worldwide, please go to www.beyerdynamic.com Non-contractual illustrations. Subject to change without notice.